
Power Supply EL630-1203-7



## General information:

**EL630-1203-7** has been specifically developed to meet the DC powering requirements for telecommunications, industrial and marine applications. The output is current limited, with short circuit protection. EL630-1203-7 is a high quality and reliable linear power supply with build in a 12V 7Ah battery. The power supply work in parallel with the 12V battery, giving a no-break power supply for different electronic equipments such as fire alarm systems, intruder alarm, access control systems aso. EL630-1203-7 has relay contact output (potential free) giving information about battery condition, mains and charger failure. Light emitting diodes indicates battery condition, mains/charger "OK", overload and fuse errors.



#### Details

Tamper switch



Address: Nedre Rommen 5 N-0988 Oslo Norway Battery cables with fuse (30A) included



Ventilation holes




Ph:+47-2210 5060 Fax:+47-2210 5030 E-mail: company@elreg.no Internet: http//www.elreg.no Doc.No: EL630-1203-7 TE Rev.2.01.doc Dato: 16.06.05

#### TECHNICAL DOCUMENTATION









## • EL630-1203-7 key data:

- Output power (13,8V/3A)
- 2 output circuits with fuses and LED's which illuminates by fuse break.
- Temperature compensated chargervoltage.
- Potential free alarm output for main/charger fault and battery failure.
- Separate input for battery connection to achieve a "No-Break distribution system"
- Built in battery test function, controlled automatically or externally.
- Automatic protection against deep discharging of the battery.
- Approved by NEMKO and marked with CE label.



**TECHNICAL DOCUMENTATION** 

Power Supply EL630-1203-7



# BATTERY

## **Battery supervision** and battery protection

EL630-1203-7 has an automatic battery test procedure. The battery will be tested every 3 min. If the battery voltage falls below 12V, the LED marked BATTERY OK will be switched off.

This LED will illuminate again when battery voltage increases to 11,9V.

When mains disappear, the battery will supply current to the load and the LED will start flashing.

During mains failure the battery will be discharged. In order to protect the battery from completely discharging and risk for destroying, the load will be disconnected when the battery voltage has fallen down to 9,5V.

When the mains is back and the voltage has increased to 11,9V, the load will automatically be connected to the power supply again.



#### Supervising the Mains and the Charger

The LED marked MAINS/CHARGER OK illuminates when the charger supplies current.

This LED will turn off when the charger stops supplying current.



#### <u>Alarm outputs</u>

EL630-1203-7 has common output in order to send information about battery condition and mains/charger

condition externally. The relay contact are potential free and withstand a current up to 2 Amps

### Mains/Charger and battery faults:

Relay contacts marked COMMON and NORMALY CLOSED is connected by battery fault or mains/charger fault



#### Protection against overload and short-circuiting:

The rectifier will limit the output current to max 3,5A and the output voltage decrease in order to maintain the output

current constant without any danger for the

power supply. The charger is equipped with 2 separate outputs, each with a 5 amp fuse.

The basic purpose of these fuses are to protect the battery against irregular current draw.

Red LED's placed with fuses illuminates when the respective fuses are broken. The LED's will only illuminate if a load is connected to the power supply.

#### Over voltage protection:

The Mains input is protected by a MOV (Metal oxide varistor) against transients and over voltage.

# Power Supply EL630-1203-7





210 - 250VAC 50-60 Hz 78W (On full load on all outputs) Yes, MOV (metal oxide varistor) 20x5mm glass fuse 1A slow blow Screw terminals max 2,5mm<sup>2</sup>

13,8VDC +/- 100mV (Adjustable +/- 2,5V) 3A continuously. 42W <0,5% by 0-100% load and/or input voltage variations from 210 to 250VAC 2 pcs. Each with a 20x5mm glass fuse 5A slow blow 1 pcs. 12V 7Ah Yes. Yes, Current limiting at 3,5Amp +/- 0,5Amp <20mV p-p DC-30MHz, measured with a noise probe direct on the output connectors. Screw terminals max 2,5mm<sup>2</sup>

Potential free relay contacts no,nc,c max load 2 Amp Potential free relay contacts no,nc,c max load 2 Amp Screw terminals max 2,5mm<sup>2</sup>

Screw terminals max 2,5mm<sup>2</sup> >65%, by full load. Yes Yes Wall mounted steel enclosure 15 kg inclusive battery L\*W\*H: 410mm\*410mm\*210mm IP 22 Free air passage -20 - +60°C

Approvals:

Meet the requirements in the safety standard EN60950. Meet the requirements in RFI/EMI standard EN55022 level B EL630-1203-7 is approved by NEMKO and marked with a CE label.



## All connections: Information output / Input:

Mains/charger faults Battery fault: Connections:

**Technical data:** 

Over voltage protection:

Input: Input voltage:

Input power:

Input fuse:

Output: Voltage:

Connections:

Current max:

Voltage accuracy:

Output circuits :

Short circuit protected

Protected against overload:

Ripple and noise on output:

Battery input:

Power max:

#### General data:


Battery connections: Efficiency: Soft start: Temperature protected: Cabinet: Weight: Dimensions: Density: Cooling: Ambient temperature:


Address: Nedre Rommen 5 N-0988 Oslo Norway Ph:+47-2210 5060 Fax:+47-2210 5030 E-mail: company@elreg.no Internet: http//www.elreg.no Doc.No: EL630-1203-7 TE Rev.2.01.doc Dato: 16.06.05 TECHNICAL DOCUMENTATION

Power Supply EL630-1203-7

A-S **elreg** More power to You !


# Dimensions and connection diagram





Address: Nedre Rommen 5 N-0988 Oslo Norway Ph:+47-2210 5060 Fax:+47-2210 5030 E-mail: company@elreg.no Internet: http//www.elreg.no Doc.No: EL630-1203-7 TE Rev.2.01.doc Dato: 16.06.05 Power Supply EL630-1203-7





# Tested by:

Date:..... Sign:....